

# Polaroid



A one-time limited-edition film that's full of surprises. This twist on the classic Polaroid film gives you a mix of 8 different metallic spectrum frames to make your photos pop. A limited edition – get it now or miss out forever.

## Color film for i-Type – Metallic Spectrum Edition




8 different metallic color frames



Polaroid's original full frame format



8 photos in a pack



Launch date	Sept 01, 2022
PRD	006220
EAN	9120096774294
GTIN	19120096774291
HS or HTS Code	3701200000 (EU), 3701200030 (US)
Country of origin	NL
Finish	Glossy
Warranty info	<a href="https://polaroid.com/warranty">polaroid.com/warranty</a>
Format	3.5" x 4.2" (88mm x 107 mm)
Image Area	3.1" x 3.1" (79 mm x 79 mm)
Battery report	No Battery – no UN38.3



ASA 640 <sup>[1]</sup>



Photos develop in 10-15 mins



Best stored refrigerated <sup>[2]</sup>

<sup>[1]</sup> Film speed may vary, allow for +/- 1/3 stops

<sup>[2]</sup> Do not freeze film

### Store chilled, shoot warm

Temperature affects how the film works. Keep it stored cold in the fridge, but never freeze it. Ideally you should let it adjust to room temperature before you use it. That's around 55–82°F (13–28°C). When it's cold out, keep your photos warm in a pocket close to your body while they develop. Or if it's a hot day, make sure they stay cool.

### Shoot with the light

The more light in your shot, the better your photo will turn out. Instant film loves light, especially natural light. Use the flash for all your indoor photos. For best results we also recommend using the flash for outdoor shots, unless it's a bright sunny day.

### Develop in the dark

All photos appear blank at first. They're most sensitive during this time, so don't bend or shake them. Shield them from the light, and place them face down as they develop. Keep B&W photos shielded from light for about 1 minute, and color film for about 6 minutes.

### Care for your camera

Your camera has a set of rollers inside the film door. Each photo passes through these rollers as it's made, so it's important to make sure that they stay clean. If the rollers get visibly dirty then gently wipe them down with a soft, damp cloth.

### Works with:



i-Type  
Cameras



Polaroid Lab

### Does not work with:



Vintage  
Cameras



Go  
Cameras

### Have a question you need answered? Contact our Customer Support Team

USA/Canada  
[usa@polaroid.com](mailto:usa@polaroid.com)  
+1-212-219-3254

EU/Rest of the World  
[service@polaroid.com](mailto:service@polaroid.com)  
00800 5770 1500

Or visit [polaroid.com/help](https://polaroid.com/help)